

MOST Commonly Replaced Parts List

Zebra

110PAX 3

*High Wear Parts

Description	Part Number
1 Belts: 112PAX3 (203 dpi) RH/LH	42-49122 42-43140
2 Belts: 113PAX3 (300 dpi) RH/LH	42-49122 42-43140
3 Belts: 116PAX3 (600 dpi) RH/LH	42-49122 42-45189-20 42-43140M
4 Board, Applicator Interface PCB, Std.	42-43447M
5 Board, Ribbon Tension Control PCB	42-G43210M
6 Flag, Head-open kit, Xill/Xiill Series	42-HW46352
7 Peel Bracket (Roller) Asy. Maint. Kit	42-43310M
8 Pulley, Compound w/Platen Belt (49122) - 203/300 dpi (RH)	42-43311M
9 Pulley, Compound w/Platen Belt (49122) - 203/300 dpi (LH)	42-43393M
10 Pulley, Compound w/Platen Belt (49122) - 600 dpi (RH)	42-43721M
11 Pulley, Compound w/Platen Belt (49122) - 600 dpi (LH)	42-43720M
12 Ribbon Strip Plate	42-43049
13 Roller, Elastomer Peel, Maint. Kit	42-43118M
14 Roller, Elastomer Pinch Maint. Kit	42-43006M
15 Roller, Platen	42-G43110M
16 Sensor, Cover/Door Open Maint. Kit	42-43394M



Low Wear Parts

Description	Part Number
1 Bearing, Ball, Elastomer Peel/Pinch (inner)	42-49237
2 Bearing, Ball, Elastomer Peel/Pinch (Outter)	42-44423
3 Bearing, Ball, Flanged (Main Platen Roller)	42-49246
4 Board, Main Logic PCB	42-43402M

***To ensure availability and reduce experiencing a major equipment outage, Labeltronix strongly recommends purchasing a minimum of one of each item.**

Continued

For Parts Call: **800 429 4321** or email us at
parts@labeltronix.com

MOST Commonly Replaced Parts List

LabelAire

110PAX 3

Low Wear Parts



Description	Part Number
5 Bracket, Printhead Mount (LH)	42-43071
6 Bracket, Printhead Mount (RH)	42-43041
7 Bracket, Printhead Mount (600 dpi - LH)	42-43590
8 Bracket, Printhead Mount (600 dpi - RH)	42-43535
9 Power Supply, AC	42-43236M
10 Power Supply, DC (LH)	42-G43240M
11 Power Supply, DC (RH)	42-G43238M
12 Pulley, Stepper Motor Maint. Kit (203dpi)	42-G57604M
13 Pulley, Stepper Motor Maint. Kit (300dpi)	42-57464M
14 Sensor, Lower Media Maint. Kit (RH)	42-G43212M
15 Sensor, Lower Media Maint. Kit (LH)	42-G43250M
16 Sensor, Printhead Open	42-37920
17 Sensor, Ribbon (LH)	42-43467M
18 Sensor, Ribbon (RH)	42-G46665M
19 Sensor, Upper Media Maint. Kit (LH)	42-G43084M
20 Sensor, Upper Media Maint. Kit (RH)	42-G43214M
21 Sensor, Lower Media Maint. Kit (LH)	42-G43250M
22 Sensor, Lower Media Maint. Kit (RH)	42-G43212M
23 Sensor, Ribbon (RH)	42-G46665M
24 Sensor, Ribbon (LH)	42-43467M
25 Sensor, Upper Media Maint. Kit (LH)	42-G43084M
26 Sensor, Upper Media Maint. Kit (RH)	42-G43214M
27 Switch, Power, Rocker	42-49512
28 Toggle, Asy., Printhead	42-43053M

***To ensure availability and reduce experiencing a major equipment outage, Labeltronix strongly recommends purchasing a minimum of one of each item.**

<mailto:parts@labeltronix.com>

For Parts Call: **800 429 4321** or email us at
parts@labeltronix.com